



Position No, 5 is standard unless otherwise specified by customer. If at all possible, try to avoid Position No. 13-18 on 20HP Blowers because of air filter and motor electric box interference.

**Position No. 3 for HP Enclosure.
Position No. 9 for LP Enclosure.

Blower Housing Positioning	BlowerPos
----------------------------	-----------